

**USER GUIDE FOR
DECO ROUND DINING TABLE 494574**



Place the base on the flat floor. Put the top onto the base, align the brass indicator mark on bottom panel of the top and base in a straight line, make sure holes to fit connectors are coincided, then secure them tightly with the 4 connector bolts provided

